at&t

user's manual

coolBlu

model #: ID102

Made for iPod iPhone

Music Dock for iPhone® and iPod®

hello.



Thank you for purchasing coolBlu [ID102].

Music Dock for iPhone® and iPod®

Features

· Speaker dock for iPhone and iPod
· FM radio
· Alarm clock
· Built in stereo speaker
· Line-In Jack for use with other devices
· Play & charge your iPhone and iPod simultaneously

iPhone and iPod are registered trademarks of Apple Inc.

What's Included

Unpack the docking station and make sure all accessories are put aside so they will not be lost.



iPhone/iPod Dock Adapters



AC Adapter



Docking Station

Contents

Introduction 2

What's Included 3

Safety Information 5

Getting Started

- Location of Controls 8
- Power Supply 9
- Back Up Batteries 9
- Preparation for Use 9
- Dock Adapters 10

Operational Instructions

- Dimmer Function 11
- Setting the Digital Clock 11
- Alarm Functions 12
- Electronic Volume Control 14
- Radio Operation 15
- Operation with iPhone and iPod 16
- Music Equalizer 17
- Connecting Other Devices (AUX-INPUT) 17

Troubleshooting 18

Compliance with FCC Regulations 19

Specifications 20

Warranty Information 21

Safety Information

Warning!

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO DRIPPING OR SPLASHING LIQUIDS.

The lightning flash and arrowhead symbol within the triangle is a warning sign alerting you of "dangerous voltage" inside the product.

WARNING: To reduce the risk of electric shock, do not remove cover (or back). There are no user-serviceable parts inside. Refer servicing to qualified service personnel.

The exclamation point within the triangle is a warning sign alerting you of important instructions accompanying the product.

NOTES: Caution symbols are printed on rear of docking station.
Please refer to user's manual.
This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Important Safety Instructions

When used in the directed manner, coolBlu has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in this user's manual and on the docking station.

1. **CLEANING** - Unplug the docking station from the wall outlet before cleaning. Clean the docking station using a damp cloth; do not use liquid or aerosol cleaners.
2. **ATTACHMENTS** - Do not use attachments not recommended by the manufacturer.
3. **ANTENNA** - Do not connect an external antenna to the docking station (other than that provided).
4. **WATER AND MOISTURE** - The docking station should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
5. **PLACEMENT** - Do not place the docking station on an unstable table, stand, tripod, or bracket. This may result in serious personal injuries and damage to the docking station.
6. **VENTILATION** - The docking station should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
7. **PERIODS OF NON-USE** - If the docking station is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the docking station to prevent damage or corrosion.
8. **OBJECTS AND LIQUID ENTRY** - Care should be taken so that external objects do not fall into and liquids are not spilled onto any openings or vents located on the product.
9. **POWER SOURCE** - The docking station should be connected to a power supply only of the type described in the operating instructions or as marked on the docking station. If you are not sure, please consult the dealer or local power company.
10. **POWER CORD PROTECTION** - Power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against it. It is always better to have a clear area from where the cable exits the docking station to where it is plugged into an AC outlet.
11. **LIGHTNING** - Unplug the docking station from the wall outlet and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
12. **OVERLOADING** - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
13. **HEAT** - The docking station should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
14. **DAMAGE REQUIRING SERVICE** - The docking station should be serviced by qualified service personnel when:
    A. the power supply cable or plug has been damaged.
    B. objects have fallen into or liquid has been spilled onto the enclosure.
    C. the docking station has been exposed to rain.
    D. the docking station has been dropped or the enclosure damaged.
    E. the docking station exhibits a marked change in performance or does not operate normally.

Safety Information

15. **SERVICING** - The user should not attempt to service the docking station beyond those methods described in the user's manual. Opening or removing covers will expose you to dangerous voltage and other hazards. Service methods not covered in the user's manual should be referred to qualified service personnel.
16. **SAFETY CHECK** - Upon completion of any service or repair to the docking station, ask the service technician to perform safety checks to determine that the product is in proper working condition.

Location of Controls



1. Speaker
2. Blue backlit display
3. Back-up battery compartment (Bottom of docking station)
4. Cavity for dock adaptor
5. Dock adaptor for iPod (Several different adaptors are provided)
6. VOLUME DOWN (-) button
7. VOLUME UP (+) button
8. MEMORY button
9. EQ/SLEEP button
10. ON/OFF button
11. SKIP (-)/SEARCH (-) button
12. SKIP (+)/SEARCH (+) button
13. AL-MODE/AL-SET button
14. FUNCTION/CL-SET button
15. PLAY/PAUSE/STEREO/MONO button
16. SNOOZE/DIMMER button
17. AUX-INPUT socket
18. DC jack (DC 6V ⎓ - -⊙- +)
19. FM antenna wire

Power Supply

AC Operation (External AC-DC Power Adaptor)

- coolBlu is equipped with a “DC-jack” that should only be used with the supplied AC-adapter to operate the docking station. Use of other adaptors may damage the docking station or cause it to malfunction.
- Plug the tail end of the AC-adaptor into the DC-jack (socket) on the rear of the docking station.
- Insert the plug of the AC-adaptor into a wall outlet with AC-power and not controlled by a wall switch.
- Press the ⏻ button to switch on the docking station.
- coolBlu is designed to operate without ever being totally powered “OFF”. It will either be “ON” or in “STANDBY” mode.
- In “STANDBY” mode, the blue backlit digital display will be dimmed, but the display will show the current time (clock function).
- From “STANDBY” mode, you can switch “ON” the docking station by pressing the ⏻ button.
- Save energy by switching the system to “STANDBY” mode when not in use.

Back Up Batteries

- Open the battery door at the bottom of docking station.
- Insert 2 “AAA” batteries (not included) in the battery compartment. The 2 batteries supply backup power for the current time clock and radio memory preset stations during brief power outages.

Preparation for Use

- Before connecting your iPhone/iPod to coolBlu, it is recommended to insert the proper dock adapter for your iPhone/iPod model. coolBlue includes dock adaptors that work with several models of iPhone and iPod.
- If you want to connect a different model iPhone or iPod at a later time, you can easily remove the dock adaptor from your speaker system using a fingernail, and insert the adaptor that fits the new iPod.

Dock Adapters

Choose the dock adapter that fits your iPhone/iPod and insure your iPhone/iPod fits snugly into the correct adapter.

- iPhone
  iPhone 3G
  iPhone 3Gs
  iPhone 4
  — 15 OR 19
- iPod touch
  4th generation
  8GB
  32GB
  64GB
  — 20
- iPod touch
  1th generation
  2nd generation
  3rd generation
  — 14 OR 16
- iPod classic
  80GB
  120GB
  160GB
  — 9 OR 10
- iPod
  5th generation
  (video)
  30GB
  60GB
  80GB
  — 9 OR 10
- iPod nano
  5th generation
  (video camera)
  8GB
  16GB
  — 18
- iPod nano
  4th generation
  (video)
  8GB
  16GB
  — 17



Dimmer Function

coolBlu has a dimmer function to adjust the brightness level of the display backlight to reduce eye strain and save energy. Simply adjust as desired by pressing the **SNOOZE/ DIMMER** button repeatedly (hi-dimmer/low-dimmer/OFF). The display backlight will always return to low-dimmer after reset of the docking station.

Setting the Digital Clock

Press the ⏻ button to turn the docking station into “STANDBY” mode. In “STANDBY” mode, the display will continuously show the current time.
In this situation the blue backlight is normally dimmed to save electricity.


how to set the correct time
Switch docking station to “STANDBY” mode (display light = dimmed)
Press & hold the FUNC./CL-SET button for 3 seconds. Display shows “12H” Hour or “24H” hour (flashing)
Press the < or > button to select 12-hour or 24-hour clock display system & press the FUNC./CL-SET button to confirm your selection
Press the < or > button repeatedly to set the correct hour in the display & press the FUNC./CL-SET button to confirm
Press the < or > button repeatedly to set the correct minute in the display & press the FUNC./CL-SET button to confirm
Correct time is now set & will be shown on the display.

Alarm Function

coolBlu is equipped with 3 alarm modes: buzzer, radio and iPod. Before setting the alarm, make sure to set the clock (see “Digital Clock Function” on page 11) .

Alarm Time Setting

3. Hour (Flashing)



4. Minutes (Flashing)

1. Please make sure the docking station is in “STANDBY” mode. (LED clock dimmed)
2. Press the ⏻ button to put the docking station into “STANDBY” mode (blue backlight dimmed).
3. Press and hold **AL-MODE/AL-SET** button until the hour digits on the display are flashing.
4. Press the < or > button to reach the hour of the desired WAKE UP time; then press **AL-MODE/AL-SET** button to confirm. The display will now show the minute digits flashing.
5. Press the < or > button to reach the minutes of the desired WAKE UP time, then press the **AL-MODE/AL-SET** button to confirm.
6. Select the desired source that the docking station will play at the “WAKE UP” time.: Press the ⏻ button to switch on the docking station (display blue light will be “ON”).

1) For iPhone or iPod : Connect the iPhone or iPod to the docking station.
Select the song or the desired playlist to play at the “WAKE UP” time. Start and pause playback of the song/playlist at the point from which you want playback to begin at the “WAKE UP” time.
For radio : Tune in the desired station.
For buzzer : No preparation is required.

2) Adjust the volume level as desired by pressing 🔉 or 🔊 button. Once the desired source has been prepared, press the ⏻ button to put the docking station into standby mode. Press the **AL-MODE/AL-SET** button repeatedly to select the source as desired. The AL(buzz)/iPod/FM lights flash in sequence until the desired source is selected.

7. The alarm time is now fully programmed and the alarm symbol will appear to indicate that the alarm function is “ACTIVE”.
8. The docking station will now automatically switch “ON” at the wake up time you have chosen, as long as the alarm function is “ACTIVE”.
9. To turn off the docking station after it has automatically switched on, simply press the ⏻ button once. This will switch off the docking station but will not clear the alarm settings. The docking station will switch on again automatically on the next day at exactly the same preset time.
10. To deactivate the alarm, press continuously the **AL-MODE/AL-SET** button until symbol “AL” disappears from the display.
11. To activate the alarm again, repeat the procedure of “ALARM TIME SETTING”.

important!

If the alarm is set to iPod, you need to make certain the iPhone or iPod is connected properly and using docking station power rather than the battery power of the device. Otherwise, the buzzer alarm will sound at the set time.

Snooze Function

- When the alarm rings, it can be temporarily suspended for a short period of 9 minutes, by pressing the **SNOOZE/DIMMER** button once. In this period, you will observe “AL” icon flashing on the display.
- The alarm will then automatically come on again after the 9 minute “SNOOZE” period has ended.
- The procedure can be repeated for approximately 90 minutes from original alarm wake up time.

Automatic Power Off Sleep Function

- coolBlu has a special sleep function which, when set, will automatically switch the docking station off after a preset amount of time. This is useful for sleeping to music at night.
- At any time while the docking station is operating, press & hold the **EQ/SLEEP** button until the “SL” symbol flashes. Press the **EQ/SLEEP** button repeatedly to choose the desired automatic power off time. In this period, you will observe “SL” icon on the display.

* OFF means sleep timer is deactivated

Electronic Volume Control

- To increase or decrease the loudness of coolBlu, press the ◄) or ◄))) button respectively.
- Release the button when the desired volume level is reached.
- Sometimes, especially when listening to the radio, you may notice a “click-click-click” (repeating) sound when you are increasing or decreasing the volume. This is a normal condition & the sound will disappear when you release the volume button.

Operational Instructions

Radio Operation

- Press the ⏻ button to turn the docking station on.
- Press the **FUNC./CL-SET** button repeatedly until the display shows “FM”.
- Extend and adjust the FM-wire antenna to obtain the best reception.
- Use the ⏯ button to select the desired mode (stereo/mono). In stereo mode, you will observe “ST” icon on the display. Whereas in mono, no icon is observed on the display.
- In some cases where reception is poor, it may be advisable to select “MONO” mode to improve clarity of the radio signal.

Manual Station Adjustment (Scan Mode)

- Press (and immediately release) the < and > buttons to “SCAN” (manually adjust) the radio stations “UP” or “DOWN” 1-frequency at a time.
- The digital display will indicate the exact station at each step’s position.
- When a desired station is reached, it can be saved into one of the “MEMORY” positions. (See “RADIO MEMORY” section below.)

Automatic Station Adjustment (Seek Mode)

- Press and hold (for 2 seconds) the < and > buttons to automatically “SEEK” the radio stations “UP” or “DOWN” to the next available station in your area.
- The digital display will indicate the exact frequency of the next station that is found.
- When a desired station is reached, it can be saved into one of the “MEMORY” positions. (See “RADIO MEMORY” section below.)

Radio Memory (Station Preset Memory Storage)

- At any time, the currently displayed station or frequency can be stored into one of the memory positions.
- Press and hold the **MEMORY** button until “C01” flashes in the display.
- Press the < and > buttons to select desired memory position. (There are a total of 30 memory positions.)
- Press the **MEMORY** button once to save the selected station into the selected memory position.
- To recall any station saved to memory, simply press the memory button once and use the < and > buttons to navigate your preset stations.
- To clear the memory of any position, simply save a new station to the same memory position.

Operation with iPhone or iPod

- Turn on the docking station and the iPhone or iPod.
- Insert the iPhone or iPod into the docking station.
- Press the **FUNC./CL-SET** button repeatedly until the display shows “iPod”.
- Press the ⏯ button on the docking station to begin playback.
- The iPhone/iPod display will indicate the information of the current song.
- At anytime during playback, press the ⏯ button to pause playback.
  Press ⏯ button to resume playback of the same song and position.
- At anytime during playback, press and release the < and > buttons to skip forward or backwards by one song, as desired.
- At anytime during playback, press and hold the < and > buttons to fast-forward (cue) or fast-reverse (review) the current song.
- You can operate the iPhone/iPod using either the docking station’s buttons, or directly with the iPhone/iPod itself.
- When your iPhone/iPod is connected to the docking station, it will start charging the battery of the iPhone/iPod.
- It is recommended that playback of your iPhone/iPod be paused before removing it from the docking station to prevent damage to your song files.

“Made for iPhone” and “made for iPod”, means that an electronic accessory has been designed to connect specifically to iPhone and iPod respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPhone and iPod may affect wireless performance.

Made for iPod iPhone

Operational Instructions

Music Equalizer

At anytime during playback, press the **EQ/SLEEP** button repeatedly to choose the desired sound effect according to the music you are listening to :



Using the Audio Line in Connection (AUX-INPUT)

- You can connect the audio input of an external device, such as a MP3 player or a TV, to coolBlu for listening to the sound of that device through the high quality amplifier of the docking station.
- To connect the external device, use a standard stereo headphone (3.5 mm) cable. Connect the “HEADPHONE-OUT” or “AUDIO LINE-OUT” of the device to the AUX-INPUT socket of this docking station.
- Switch on the docking station and the external device (eg. MP3-player or TV).
- Switch the function to AUX using the **FUNC./CL-SET** button.
- Start playback of the external device and adjust the volume control of the docking station to the desired level.
- Remember to switch off the docking station when you are finished using the external device.

Troubleshooting

Symptom	Possible cause	Solution
coolBlu does not respond (no power)	AC adapter is not plugged into a wall outlet or the connector is not plugged into the DC IN jack on the back of the docking station.	Verify the AC adapter is plugged into wall outlet and the DC IN jack properly.
iPhone/iPod does not dock properly	Using no or wrong iPhone/iPod dock adapter.	Make sure the dock adapter is the proper fit for the iPhone/iPod.
	iPhone/iPod is not installed properly.	Remove the iPhone/iPod from the docking station and check for obstruction on the connections of the docking station and of the iPhone/iPod. Then reset the iPhone/iPod into the docking station.
iPhone/iPod does not respond to the coolBlu	iPhone/iPod is not installed properly.	Remove the iPhone/iPod from the docking station and check for obstruction on the connections of the docking station and of the iPhone/iPod. Then reset the iPhone/iPod into the docking station.
	iPhone/iPod is locked up/frozen.	Make sure your iPhone/iPod is working properly before docking it into the docking station. Please refer to the iPhone/iPod manual for details.
	Using first or second generation iPod, iPod shuffle or other devices.	coolBlu cannot control these iPods or other devices.
iPhone/iPod is not charging	iPhone/iPod is not installed properly.	Remove the iPhone/iPod from the docking station and check for obstruction on the connections of the docking station and of the iPhone/iPod. Then reset the iPhone/iPod into the docking station.
	iPhone/iPod is locked up/frozen.	Make sure your iPhone/iPod is working properly before docking it into the docking station. Please refer to the iPhone/iPod manual for details.
	iPhone/iPod battery has a problem.	

Remarks:
If troubleshooting does not eliminate the problem, disconnect the DC IN plug from the back of docking station and reconnect it after a few seconds. This resets the docking station to it's factory default settings and results in the deletion of all previous settings. In case the problem still exists, see warranty information on page 21 to obtain service.

Compliance with FCC Regulations

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate Radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to Radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to Radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit other than, to which the receiver is connected.
- Consult the dealer or an experienced Radio / television technician for assistance.

THE SPECIFICATION AND EXTERNAL APPEARANCE OF THE MUSIC DOCK ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

If at any time in the future you should need to dispose of this product please note that: waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Specifications

- Power supply: DC 6V, 2Amps through built-in DC jack
  External AC-DC power adaptor 110V-240V ~ 50/60Hz
- Power consumption: 10 W
- Speaker: 2" x 2
- Frequency: FM 87.5-108 MHz

Warranty Information

Limited Warranty

The AT&T brands are used under license. Any repair, replacement, or warranty service, and all questions about this product should be directed to Concept 101 LLC at **www.att.com/electronics** or call **1 (888) 920-8680** from the USA or Canada.

Concept 101 LLC warrants to the original purchaser that the product will be free from defects in material, parts and workmanship for the period designated for this product. The warranty commences the day the product is purchased and covers up to a period of one (1) year (90 day Labor and 1 year Parts). Concept 101 LLC agrees that it will, at its option, replace the defective product with either a new or remanufactured docking station equivalent to your original purchase during the warranty period. Should the Parts warranty period exceed the Labor warranty period, Concept 101 LLC will supply at no charge for the remainder of the Parts warranty, any new or remanufactured replacement parts as required by the product. During this period all labor and service charges will become the responsibility of the customer.

Exclusions: This warranty does not apply to the appearance or exterior of the product which may have been damaged or defaced, altered or modified in design or construction. Further, this warranty does not apply if the serial number is altered or removed, or if there is any damage due to power line surge, user damage to the AC power cord, connection to improper voltage source, general misuse, accidents, or repair attempts by unauthorized service agents. Other exclusions include ear pads, rechargeable and non-rechargeable batteries.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER; Concept 101 LLC SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THE WARRANTY.

Some states do not allow the exclusion or limitations of incidental or consequential damages, or limitations on how long the warranty lasts. In these cases the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Obtaining Service: To obtain service, product literature, supplies or accessories please call **1 (888) 920-8680**, or visit our website, **www.att.com/electronics**, to create a ticket for exchange/repair. Please make sure to provide the date of purchase, model number and a brief description of the problem. Our customer service representative will contact you or send detailed return instructions.

Concept 101 LLC does not warrant that the docking station will work properly in all environmental conditions, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose other than the purpose identified within this user's manual. Concept 101 LLC has made every effort to ensure that this user's manual is accurate, and disclaims liability for any inaccuracies or omissions that may have occurred. Information in this user's manual is subject to change without notice and does not represent a commitment on the part of Concept 101 LLC. Concept 101 LLC reserves the right to make improvements to this user's manual and/or to the products described in this user's manual, at any time without notice. If you find information in this manual that is incorrect, misleading, or incomplete, please contact us through our website.

Memo

www.att.com/electronics

©2012 Concept 101 LLC. All Rights Reserved. AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to Concept 101 LLC, New York, New York 10018. Printed in China. Issue 14 AT&T 03/2012.